























Crane Works, L.P.



MOBILE CRANE SIGNALS

ALWAYS STAND IN CLEAR VIEW OF YOUR CRANE OPERATOR

HOIST	LOWER	USE MAIN HOIST	USE WHIP LINE
			
HOIST: With forearm vertical, forefinger pointing up, move hand in small horizontal circles.	LOWER: (Auxiliary Hoist) With arm extended downward, forefinger pointing down, hand in small horizontal circles.	USE MAIN HOIST: Tap fist on head, then use regular signals.	USE WHIP LINE: (Auxiliary Hoist) Tap elbow with one hand, then use regular signals.
RAISE BOOM	LOWER BOOM	MOVE SLOWLY	RAISE THE BOOM AND LOWER THE LOAD
			
RAISE BOOM: Arm extended, fingers closed, thumb pointing upward.	LOWER BOOM: Arm extended, fingers closed, thumb pointing downward.	MOVE SLOWLY: Use one hand to give any motion signal and place other hand motionless in front of hand giving the motion signal. (Hoist slowly shown as example)	RAISE THE BOOM AND LOWER THE LOAD: With arm extended, thumb pointing up, flex fingers in and out as long as load movement is desired.
LOWER THE BOOM AND RAISE THE LOAD	SWING	STOP	EMERGENCY STOP
			
LOWER THE BOOM AND RAISE THE LOAD: With arm extended, thumb pointing down, flex fingers in and out as long as load movement is desired.	SWING: Arm extended, point with finger in direction of swing of boom.	STOP: Arm extended, palm down, move arm back and forth horizontally.	EMERGENCY STOP: Both arms extended, palms down, move arms back and forth horizontally.
TRAVEL	DOG EVERYTHING	TRAVEL (Both Tracks)	TRAVEL (One Track)
			
TRAVEL: Arm extended forward, hand open and slightly raised, making pushing motion in direction of travel.	DOG EVERYTHING: Clasp hands in front of body.	TRAVEL (Both Tracks): Use both fists in front of body, making a circular motion about each other, indicating direction of travel, forward or backward. (For land cranes only.)	TRAVEL (One Track): Lock the track on side indicated by raised fist. Travel opposite track in direction indicated by circular motion of other fist, rotated vertically in front of body. (For land cranes only.)
EXTEND BOOM	RETRACT BOOM	EXTEND BOOM	RETRACT BOOM
			
EXTEND BOOM (Telescoping Booms): Both fists in front of body with thumbs pointing outward.	RETRACT BOOM (Telescoping Booms): Both fists in front of body with thumbs pointing toward each other.	EXTEND BOOM (Telescoping Booms): One Hand Signal. One fist in front of chest with thumb tapping chest.	EXTEND BOOM (Telescoping Booms): One Hand Signal. One fist in front of chest, thumb pointing outward and heel of fist tapping chest.

EMERGENCY CONTACTS

COMPLIMENTS OF MAXIM CRANE WORKS SAFETY DEPARTMENT
1 (877) MAX-LIFT www.maximcrane.com **1 (877) 629-5438**